JTR1

REMOTE ACCESS FOR JOULEALARM AND JOULETEMP

► GSM Modem to access multipe controls pre configured <




Now you can access any JouleTemp or JouleAlarm any where, any time!

With JTR1 plugged into your Jouletemp you are able to access Jouletemp and Joulealarm from the internet, using your web browser on your phone, tablet or PC. And the access will be as simple as typing a site like jouletemp.dyndns.net into your browser!

JTR1 comes complete with a datasim card (to be activated by customer), we have preconfigured the setup so you are able to go into your Jouletemp(s) and look at temperature graphs, alarms defrost and even change settings from anywhere.

JouleTemp can even be configured to send SMS and emails¹ to you in the event of alarms so you are always 100% in control.



The modem as supplied can connect 4 Jouletemp directly or up to 32 when a switch is added.



1. Email and SMS are paid services



► Telephone +61 3 9584 5590 ► Fax +61 3 9584 5356 sales@phasefale.com.au www.phasefale.com.au